
Single Family Residential Development Guide

Metro Water Services




Process Flow Diagrams


Initiation and Availability Study



Public Extension Project (PEP) Plan Review



Construction and Inspection





Process Descriptions



Step 0: Applicant initiates the process of a securing a Building Permit

Step Detail

The process for securing a Building Permit for a residence begins with the Metro Department of Codes and Building Safety (Metro Codes). To start the process of securing a Building Permit, contact the Codes Help Desk:

Address: 800 President Ronald Reagan Way, Nashville, TN 37210

Hours: Monday-Friday, 7:30 a.m.-4:00 p.m.

• Email: <u>zoninghelpdesk@nashville.gov</u>

Phone Number: 615-862-6510

A Codes Zoning Examiner will work with the Applicant to identify the Metro Departments that must be involved for the Building Permit to be completed. Applicants should keep these factors in mind:

- It is the Applicant's responsibility to follow the requirements of the checklist on the building permit application and to make sure all necessary signoffs are achieved.
 Currently, Metro Nashville does not have the technology to route the application through each step in the required process; that is the Applicant's responsibility.
- It is also the Applicant's responsibility to schedule the necessary inspections with Metro Nashville at the proper time in the building process.
- Do not seek to determine what reviews and permits are required on your own. That is
 the Codes Zoning Examiner's job. If an Applicant fails to complete the steps identified in
 the permit application, the Building Permit process will be delayed.
- Allow plenty of time. The Metro agencies involved in the review process are dealing with an unprecedented number of permit applications.

If a single-family residential development includes only one (1) or two (2) units, continue to Step 1.

If a single-family residential development is three (3) or more units, skip to <a>Steps 2-6 marked as (CS) for "Capacity Study"



Associated Links & Forms

<u>Fee Schedule</u> <u>Residential Building Permit</u>

Step 1: Applicant contacts MWS DS to receive sign-off on the Building Permit Application

The Applicant for a single-family residential project with one or two units must reach out to the MWS DS group to receive sign-off on Section E of the Building Permit Application. The best way to contact this group is via email: mws.ds@nashville.gov.

A staff member from the MWS DS group must determine if there is adequate water and sewer capacity for the proposed project. From this analysis, three common courses of action may be determined:

- Scenario 1 A residential permit is requested for a new residence or residences on a vacant property. The public water line from which the proposed residence(s) will receive service is 6" or greater. The public sewer line is adequate to serve the residence(s). The MWS DS staff member creates water and sewer capacity fees, as well as water and sewer tap fees. This information is communicated to the Applicant. Once the Applicant pays the fees, the MWS DS staff member signs off on the Applicant's Building Permit Application. The Applicant is done with the process until the time at which the tap is to be scheduled and/or the Applicant seeks a meter permit. See Step 15.
- Scenario 2 A residential permit is requested for a new residence or residences on a vacant property. The public water line from which the proposed residence(s) will receive service is 4" or 2". MWS DS must send the information to the MWS Engineering modeling group to determine capacity and approval. If sufficient water and sewer capacity is determined, the process continues as with Scenario 1 above. If water and/or sewer capacity is determined to be insufficient, then a public water and/or sewer extension is required. See Step 7 to begin that process.
- **Scenario 3** In many circumstances, the Applicant seeks to tear down one residence and to construct two in its place. This scenario is subject to rules associated with Metro's



Horizontal Property Regime (HPR). The Applicant generally has two Building Permit Applications that they must contact MWS DS about. In most cases, the Applicant will have already filed for a demo permit for the existing structure. The MWS DS staff member reviews the project. If the water line serving the property is 4" or 2", then the **Scenario 2** process applies that leads to a public water and/or sewer extension project. As relates to the tap fee, the Applicant does not need to pay a tap fee for the unit that is associated with the demo permit. The Applicant receives credit for the existing connection. However, the Applicant must pay the capacity and tap fees associated with the second unit. Once those fees are paid, the MWS DS staff member signs off on the Applicant's Building Permit Application. The Applicant is done with the process until the time at which the tap is to be scheduled and/or the Applicant seeks a meter permit. See **Step 15**.

Associated Links & Forms

Fee Schedule

(CS¹) Step 2: Applicant submits request for water and sewer availability to MWS Development Services.

Step Detail

Developments with three (3) or more units constructed within the Department's water and/or sewer service areas require a determination of the availability of water and/or sewer services (a capacity study).

Applicants such as Developers and Owners, or their representatives, should contact MWS Development Services to determine water and sewer availability. This is done by using the Request for Water and Sewer Availability form located here: Request for Water and Sewer Availability.

The following information must be included (if applicable):

¹ Capacity Study Required



- Location of the property with tax map, parcel number, and Council District
- Total acreage of the site
- Intended type of development or use of the property, along with total square footage of proposed buildings
- Projected wastewater flow in gallons per day (GPD)
- Subdivision development plan with finished floor elevations
- Fire flow (this information must first be requested from the Fire Marshal fmoplans@nashville.gov)

To begin the process, the Applicant submit the <u>Request for Water & Sewer Availability Form</u> and subdivision development plan via email to: <u>MWS.DSCapacity@nashville.gov</u>. For assistance or additional information, contact MWS Development Services at (615) 862-7225.

Associated Links & Forms

Request for Water and Sewer Availability Form
Fee Schedule

(CS) Step 3: MWS Development Services performs capacity study

Step Detail

Upon receipt of a request for availability, MWS Development Services performs a capacity study to determine availability based on the projected flows for the proposed development. This study takes approximately 15 working days.

(CS) Step 4: MWS DS creates water and sewer capacity permits and capacity fees and sends to Applicant

Step Detail

Upon receipt of a request for availability, MWS Development Services performs a capacity study based on the projected flows for the proposed development in gallons per day (GPD).



Calculations are based on projected flow examples for various types of developments. MWS DS creates the resulting capacity permit and communicates the fees due by the Applicant.

Associated Forms

Fee Schedule

(CS) Step 5: Applicant pays capacity fees to MWS DS

Step Detail

Capacity fees must be paid in accordance with MWS guidelines to reserve capacity. Fees can be paid by check/cashier's check, or credit card in person with MWS DS. MWS DS is located on the first floor of the Metro Office Building, 800 President Ronald Reagan Way, 37210.

Note: The statement of sewer and water availability is effective for one year from the date of the availability letter. If, after approval of sewer and water availability, construction has not begun within the established period, a renewal of the availability statement is required and all applicable department regulations and fees in force at that time are imposed.

The request for a new capacity study must be sent to MWS.DS@nashville.gov. Capacity for the entirety of the development must be requested and purchased to reserve full capacity.

(CS) Step 6: MWS DS emails permit to Applicant

Step Detail

After capacity fee payment is made, MWS DS staff confirm the following information from the capacity study:

- Water service elevations
- Existing water main size
- Capacity purchased

This permit containing this information is sent to the Applicant via email from MWS DS. During the capacity study process, MWS determines whether a public water or sewer public extension project (PEP) is required. That is likewise communicated to the Applicant.



If a water and/or sewer service extension is NOT needed, skip to <a>Step 15

If a water and/or sewer service extension IS needed, continue with Steps 7-14 (marked as "PEP")

(PEP) Step 7: Applicant develops and submits for review construction plans for public water main and/or sewer line extensions

Step Detail

The Owner or Developer must retain the services of a State of Tennessee Professional Engineer (PE) to prepare water and/or sewer line extension construction plans. **Plans must be developed with reference to and in conformance with the requirements of the Tennessee Department of Environment and Conservation (TDEC)**. MWS has been delegated authority by TDEC to review and approve plans consistent with the governing standards found at the following sites.

- Water: <u>Plans Review and Approval for Public Water Systems (tn.gov)</u>
- Sewer: Plans Review and Approval for Sewage Works Construction Projects (tn.gov)

Applicants should also reference the information from the **Approved Construction Specifications and Details** section of the <u>Water and Sewer Information for Developers | Nashville.gov.</u>

Electronic plans must be submitted via Metro's FTP site (<u>WS FTP Server Web Transfer Client (nashville.gov</u>)). Applicants must email <u>MWS.EPlanRev@nashville.gov</u> to register and acquire a username and password to use the FTP site. Uploaded files must be named using the Site Naming Convention outlined in the Site Naming Convention document – <u>FTP Site File Naming Convention</u>.

Applicants must also pay the appropriate fee for plan review at the MWS Development Services office (Fee Schedule) located on the first floor of the Metro Office Building, 800 President Ronald Reagan Way, 37210. Payments can be made by check, cashiers' check, or credit card.

Documents required for construction plans submittal include, as applicable:

- A completed <u>Development Services Review Transmittal Form</u>
- One Water Application



- Completed <u>Technical Review Requirements</u> (TRR) form
- Fee Worksheet (see "<u>Fee Worksheet</u>" and "<u>Fee Worksheet Instructions</u>" on the following webpage: <u>Water and Sewer Information for Developers | Nashville.gov</u>
- Stamped Plans as a PDF document
- Stamped Calculations
- Capacity Permit
- Revision Letter (if applicable)

For a complete submittal of construction plans, the Applicant must provide all applicable items included on the <u>Plans Submittal Form and Checklist</u>.

If the Applicant's upload of construction plans to the FTP site is successful, the Applicant receives an email confirming such.

Associated Links & Forms

Plans Review and Approval for Public Water Systems (tn.gov)

Plans Review and Approval for Sewage Works Construction Projects (tn.gov)

Water and Sewer Information for Developers | Nashville.gov

Water and Sewer Technical Review Requirements

WS_FTP Server Web Transfer Client (nashville.gov)

Fee Schedule

One Water Application

Plans Submittal Form and Checklist

FTP Site File Naming Convention

(PEP) Step 8: MWS DS reviews the construction plans for public water main and/or sewer line extensions

Step Detail

MWS DS personnel review the public water main and/or sewer line construction plans and related materials submitted in the following manner:

An initial sufficiency review is conducted to determine if the package submitted has all
necessary documents. If the submission is not complete, the resulting email will include a
list of missing items and instructions on how to resubmit. Once a submission passes the



sufficiency review, the Applicant can track the review and approval process through ePermits.

- Submitted plans and the accompanying documents that meet the basic sufficiency requirements (that is, the submission package is complete) are assigned to a MWS DS Plan Reviewer. Using the <u>Technical Review Requirements</u> (TRR) form, the MWS DS Plan Reviewer checks the construction plan and associated documents for approximately 30 design elements that are required for an efficient and detailed review. This **TRR process** counts as the first review. A submitted construction plan that fails the TRR will be marked as "Incomplete", and the Design Engineer can log into <u>ePermits</u> to see the TRR with comments. The Design Engineer must address any issues identified in the TRR process and re-submit (see <u>Step 7</u>) the construction plan and associated documents, **including the updated TRR**.
- If the construction plan and associated documents pass the sufficiency review and the TRR, then they are subject to **full review** by the Plan Reviewer. The Plan Reviewer digitally reviews the plans and adds comments and/or markups to the construction plans. The Plan Reviewer notes issues that must be addressed to bring the submitted construction plans into conformance with applicable regulations. Depending on the Plan Reviewer, a separate comment letter may be drafted. Upon completion of the review by the Plan Reviewer, the Design Engineer receives an email that their plan review status has been changed and is directed to check <u>ePermits</u> for further details. The Design Engineer can log in to <u>ePermits</u> to see the site plan with comments.

During the plan review process, a determination is made whether any easement is required to enable the construction of the water and/or sewer line. Any required easements (on-site and off-site) must be secured **before** the plan is approved if not recorded by plat.

Associated Links and Forms

<u>ePermits</u>

Water and Sewer Technical Review Requirements
Water and Sewer Information for Developers | Nashville.gov



(PEP) Step 9: Applicant revises construction plans for public water main and/or sewer line

Step Detail

The Applicant addresses issues with the water and/or sewer line extension plans that are raised by the Plan Reviewer and brings the construction plans into conformity with all governing regulations and Plan Reviewer comments. The Applicant re-submits the construction plan and all required documents (see Step 7).

(PEP) Step 10: MWS DS approves construction plans for public water main and/or sewer line

Step Detail

Once the construction plans conform to all governing regulations, the MWS DS Plan Reviewer approves them. For the construction plans to be approved, the Applicant must have a current (non-expired) capacity letter with at least the minimum capacity fee payment applied.

See the accompanying "Lay and Deed Overview" development guide for information on the processes by which all relevant Developer commitments related to the provision of the approved water and/or sewer lines are documented by Metro's Deeds and Bonds (D&B) team.

(PEP) Step 11: Applicant contacts MWS to request scheduling of the pre-construction meeting

Step Detail

Following the Plan Reviewer's approval of the construction plans for a public extension (water or sewer), the Applicant's properly licensed Utility Contractor may contact MWS D&B (penny.gilbert@nashville.gov) to arrange to meet with MWS prior to beginning construction. A preconstruction meeting will not be scheduled until the following items are submitted to the MWS DS Plan Reviewer as indicated below:



- A signed application and applicable fees via check made payable to Metro Water Services
- Four (4) hardcopy sets of the Approved Plan, to be delivered at the preconstruction conference with material submittal and/or cut sheets
- A complete set of the Approved Plan in .DWG and .PDF format on a flash-drive or disk
- Recorded and executed easement documentation, if this easement is to be recorded by plat, provide case number
- Additional items stated on the Approval Letter
- Other permits that are needed (i.e., TDEC, TDOT, USACE, MPW ROW excavation, etc.)

This pre-construction meeting is required.

(PEP) Step 12: MWS DS schedules and conducts pre-construction meeting with Applicant

Step Detail

Prior to the pre-construction meeting for the water and/or sewer line project being held, Metro's D&B team verifies that all required approvals and easements are obtained, inspection fees paid, contractor licenses verified, and that the application for public utility extension has been secured. A D&B member prepares the construction permit for the pre-construction meeting. MWS DS D&B creates the Construction Permit, Notice to TDEC, and notifies the MWS Engineering Inspector that the projects are ready for a pre-construction meeting.

The Design Engineer, Contractor, and other specified Applicant representatives must attend the pre-construction meeting, which is hosted and conducted by the MWS Engineering Inspector. Required attendees generally include:

- Contractor
- Sub Contractor (if any)
- Design Engineer
- Developer or Developer's representative

At the meeting, the Contractor must provide sewer construction cut sheets in format acceptable to MWS and a subgrade letter for water, where applicable. The agenda for the meeting includes:



- Project details including start date, work hours, materials, scope of work, testing and disinfection
- Construction requirements
- Questions on materials
- Any other specific concerns relating to the project

After the meeting, MWS DS D&B sends the signed/dated Notice to TDEC and notifies a number of internal and external customers.

New public water and sewer infrastructure must be installed according to MWS Standards (<u>Water and Sewer Information for Developers | Nashville.gov</u>). All water- and sewer-related construction shall be inspected by MWS. The Builder or Developer must reimburse MWS for the cost of inspection (See <u>Fee Schedule</u>).

Associated Links & Forms

Fee Schedule

Water and Sewer Information for Developers | Nashville.gov

(PEP) Step 13: Applicant completes construction permit

Step Detail

If there are no major unresolved issues from the pre-construction meeting, the Construction Permit for the project is signed by the licensed municipal utility Contractor or licensed master Plumber involved in the project at MWS Development Services at the Metro Office Building, 800 President Ronald Reagan Way, 37210.

Construction may **not** begin until after the permit is signed by the Contractor and/or Plumber and received by MWS DS.

If water service is required for construction of the new mains, a temporary meter may be issued for use on a public fire hydrant. Un-metered use of Metro fire hydrants and service lines is prohibited. For a hydrant, Applicants can contact the MWS Customer Service Center by email: mwsfirehydrantgroup@nashville.gov, or 615-862-4770, ext. 78031, and follow instructions for a list of options to request a temporary meter for use on a fire hydrant.

(PEP) Step 14: Applicant constructs and conveys to MWS all planned public infrastructure

Step Detail

After the pre-construction meeting occurs and the construction permit is signed, the MWS sewer or water tap process is scheduled. All project-related activity must be coordinated through MWS Engineering Inspections.

The Contractor must provide 48-hour notice to the assigned MWS Inspector (identified at the pre-construction meeting) before commencing work. A licensed municipal utility Contractor (for sewer or water) or licensed master Plumber (for water and service lines) is required to perform all proposed public utility extension work. New public water and sewer infrastructure must be installed according to MWS standards found on the MWS Developers webpage (Water and Sewer Information for Developers) and in conformity with the construction plan that has been approved by the MWS DS Plan Reviewer.

All water- and sewer-related construction must be inspected and accepted by an Inspector from MWS's Engineering Group. Testing is done by the MWS Inspector once all new water and sewer infrastructure is correctly installed.

Sewer line testing includes:

- Air testing of all lines
- Mandrel testing of all lines
- Vacuum testing of all manholes
- CCTV of all lines

Water line testing includes:

- Disinfection of all lines
- Pressure testing of all lines.
- Connecting new water mains to the existing system (Tie-in's)

Project release requires:

- Record drawings submitted to the assigned MWS Inspector and approved (see <u>Step 25</u> for explanation of this process)
- Binder placed in roadway
- Punch list items addressed



Project closeout requires:

- Final pavement placed
- Valve op performed on any new water valve / blow-off's installed
- Final punch items are addressed

The specific details of how the newly constructed infrastructure is conveyed to Metro depend on the specifics of the project. A Letter of Equity Transfer is generally used. For example, for a traditional (25+ lot) subdivision, the early connection agreement allows for private connections to be made prior to the conveyance to Metro of the newly constructed infrastructure (Nashville.gov - Metro Water - Early Connection Agreement Form).

See the accompanying "Lay and Deed Overview" development guide for additional information on the processes by which approved water and sewer lines are conveyed to Metro ownership.

Associated Links & Forms

Letter of Equity Transfer

Nashville.gov - Metro Water - Early Connection Agreement Form

Step 15: Applicant secures Excavation Permit from NDOT

Step Detail

If a water or sewer connection (tap) is to be made in a public right-of-way, the Applicant must secure an Excavation Permit prior to the work being done. Excavation Permits are obtained from the Nashville Department of Transportation (NDOT). The Contractor performing the excavation must be licensed and bonded. The Contractor must also call 811 for a TN One Call number before any taps can be scheduled.

For more information and a copy of the Excavation Permit application, contact the NDOT at (615) 862-8782 or NDOT's website: Nashville.gov

Associated Links & Forms

Nashville Department of Transportation Permits | Nashville.gov



Step 16: Applicant contacts MWS DS to schedule the service connection (tap) and to request the meter permit

Step Detail

Tap fees for public water and/or sewer mains built by privately funded extensions

The Metropolitan Code defines developer's equity as the cost of construction of the public main extension. This amount of equity may be used to offset any required tap fees up to the cost of the public extension. The cost of each water and/or sewer tap is deducted from the amount of the developer's equity existing for the public main extension (water and/or sewer, respectively) or reimbursed to the developer, if applicable. Developer's equity for water lines may only be used for credit against water tap fees and sewer lines for sewer taps.

No connection permit can be issued to an Applicant prior to the deeding of a water/sewer main extension to MWS (if one was required by the project). The Developer must provide a signed Letter of Equity Transfer for all lots and a plat that shows the general arrangement of subdivision, lot numbers, water main sizes and locations. The letter of equity transfer accounts for the cost of each tap fee debited against the amount of the developer's equity or reimbursed to the developer if applicable.

If appropriate for the development, an early release form (<u>Early Release Form</u>) can be signed, notarized, and presented to MWS DS. Construction permit completion as well as 100% of the required availability and tap fee payment must be verified before a tap can be scheduled.

Applicants should note that paying the tap fee does **not** schedule the tap. Taps are scheduled on a first come, first serve basis.

Requests for a water and sewer service line connection (tap) should be requested by the Applicant's Plumber via the email: mws.ds@nashville.gov. At the time the tap is scheduled, the MWS DS employee provides the time and date for the tap, a map of the local infrastructure, the water/sewer main size and type, and the tap guidelines (Tap Scheduling Guidelines (nashville.gov))

For Out of County Sewer Permit Applicants

From the Applicant's perspective, the major difference on OOC (Out of County) projects is that the Applicant will not have a Metro building permit. The Applicant is responsible for notifying



MWS Development Services via email at mws.ds@nashville.gov to apply for a Metro Water Services sewer connection permit (WSST) to move forward with connections.

Once you receive a WSST number from MWS Permits, you will need to fill out this <u>request form</u> to send back to schedule a sewer inspection.

Projects in Williamson County involving a reconnect from a demo must be submitted with a demo permit from Williamson County.

Any additional information - such as a copy of the Williamson County building permit numbers or the main project numbers for connection - helps MWS Development Services issue the proper type of WSST connection permit.

Associated Links & Forms

Early Release Forms
Tap Scheduling Guidelines (nashville.gov)
Service Permit Application
Equity Transfer Letter
Fee Schedule

Step 17: Applicant picks up water meter at MWS DS

Step Detail

Applicants are encouraged to submit a request for a meter permit at the time that the tap is requested. The meter permit should be requested by way of the following form: Service Permit Application. This form must be completed and returned by a licensed Plumber. MWS DS reviews to ensure the Service Permit Application is correct and that the excavation permit has been secured (if required).

For a residential connection, the plumber will be issued a 5/8" or 1" water meter including the AMR equipment for installation. Larger residential and/or irrigation meters will be furnished by the property owner at their expense. All meters installed shall meet the automatic meter reading (AMR) requirements. List of requirements can be found at Water and Sewer Information for Developers | Nashville.gov.



Residential meters may be obtained at MWS Development Services in the Metro Office Building at 800 President Ronald Reagan Way, Nashville 37210. Approved additional meters may be purchased from a local distributor.

For more information, please email MWS Development Services at MWS.DS@nashville.gov.

The Service Permit Application information is used to establish a customer account for billing of water. Sewer billing will automatically be added to accounts 90 days later. With the issuance of the meter permit by MWS DS, the initial meter inspection is automatically scheduled for 30 business days following.

Associated Forms

<u>Service Permit Application</u>
<u>Water and Sewer Information for Developers | Nashville.gov</u>

Step 18: Applicant prepares site for the tap

Step Detail

Only MWS personnel may tap a public water or sewer main. The Applicant's Contractor must prepare the site in accordance with MWS current guidelines. These guidelines can be found at: <u>Tap Scheduling Guidelines (nashville.gov).</u>

In advance of the tap, the Contractor secures and has at the site all material necessary to complete the tap. All materials - including tap, sleeve, valves, and miscellaneous fittings required to make the tap - must be provided by the Contractor. Service lines are installed to the boundary of the property if not previously installed as a run to curb.

Associated Links & Forms

Tap Scheduling Guidelines (nashville.gov)

Step 19: MWS and Contractor complete tap and inspection

Step Detail

If the site is properly prepared with all required equipment and materials, MWS System Services completes the tap of the public water and/or sewer main. MWS Development Services Inspector inspects the water tap.

- For taps 2" or larger, the MWS Inspector takes a sample to determine if bacteria are present. This must be sent to the MWS lab and generally takes 2-3 business days to perform.
- For taps smaller than 2", only a chlorine sample is taken and reviewed on-site.

The MWS Inspector notifies the Contractor when they can connect to the public water and/or sewer system.

The sewer tap inspection is completed in coordination with the timing of the sewer tap. It may not be completed at exactly the same time as the tap but is accomplished soon after.

For Out of County Applicants

For OCC Applicants, MWS is the Metro agency that completes inspections of all sewer infrastructure from the structure to the public main.

For an OOC project, the required sewer infrastructure will be installed under one of two scenarios:

- An OOC location may have an existing tap ("stub") to which the private line can be connected. The entire sewer infrastructure still must be inspected and in compliance before the WSST permit can be approved. All sewer connections – public or private – require a WSST permit.
- An OOC location may require a new tap. In this case, the WSST permit MUST be issued before a Plumber acting on behalf of the Applicant can begin any work on the site, such as opening the trench. In this case, the standard tap process is followed, see Step 16 above.

Requirements for OOC sewer infrastructure inspections can be found here: <u>Step 16</u> LINK TO FORM. All plumbing work should be performed to pass these requirements.



After the WSST has been issued and the Plumber has completed all work according to the requirements, the Plumber or Applicant can request an OOC sewer inspection by emailing this request form to mws.ds@nashville.gov. OOC sewer inspections occur only on Monday, Wednesday, and Friday.

The MWS Inspector will indicate if a site has passed either by marking the site with blue spray paint or by way of a tag. The following day, an MWS DS representative will send a pass-fail notification to the WSST permit Applicant.

Step 20: Contractor installs water meter and water meter box

Step Detail

Meters and meter boxes are to be installed consistent with MWS specifications, which can be found here: <u>Guidelines on Installing and Inspecting Meter Boxes (nashville.gov)</u>. For helpful information on what the MWS Inspectors look for, see the meter inspection checklists and common reasons for meter failure documents under the "Policies, Procedures, and Guidelines" section at the same site.

If installation cannot meet current specifications, a Plumber can request a variance (form on website) by emailing MWS.DSVariances@nashville.gov and complete the Variance Request form.

The initial meter inspection date is set for 30 days after the permit is issued.

Associated Links & Forms

Service Request Form
Water and Sewer Information for Developers | Nashville.gov
Meter Box Specifications
Meter in Box Specifications
Variance Request Form



Step 21: MWS DS inspects water meter and water meter box

Step Detail

Inspections are automatically scheduled for 30 business days after the meter permit is issued. The Applicant can email Development Services at MWS.DS@nashville.gov to request an earlier date for a meter inspection. If an earlier inspection date is requested, it will be scheduled within 3-5 business days. An initial meter inspection date may **not** be extended beyond the original 30 business days.

For helpful information on what the MWS Inspectors look for, see the meter inspection checklists and common reasons for meter failure documents under the "Policies, Procedures, and Guidelines" section at Water and Sewer Information for Developers | Nashville.gov.

If the meter passes initial inspection, the final meter inspection date is set for 120 business days out. If the meter fails initial inspection, a re-inspection date is generated for 30 days later. A meter that passes all requirements on the initial inspection does not require a final inspection.

Associated Links & Forms

Water and Sewer Information for Developers | Nashville.gov

Step 22: Contractor installs backflow prevention device (if required)

Step Detail

For residences, backflow preventers are required to be installed for swimming pools, irrigation, and fire suppression systems. Installation of the correct backflow prevention device is the responsibility of the Plumber. They are responsible for acquiring and preparing the materials and equipment, as well as installing the backflow prevention device. Current MWS specifications for backflow prevention devices can be found at Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Developers | Water and Sewer Information for Deve

If installation cannot meet current specifications, a Plumber can request a variance (form on website) by completing the <u>Variance Request Form</u> and emailing it to <u>mws.dsvariances@nashville.gov</u>.



Associated Links & Forms

Water and Sewer Information for Developers | Nashville.gov Variance Request form Variance Requirements Backflow Preventers Specifications

Step 23: Contractor requests and MWS DS completes inspection of backflow prevention device (if required)

Step Detail

Once installed, the Applicant is responsible for completing the Backflow Prevention Inspection
Request and notifying MWS DS Inspections team at (DSInspections@nashville.gov) to schedule inspection and testing of the backflow prevention device. Costs for the testing of new devices are billed as a direct cost to the Applicant. The Applicant must have a representative present at the time of the inspection. The testing form used by MWS requires the signature of the representative to ensure knowledge of the device's performance and any potential corrective action needed.

If the backflow prevention device **passes**, MWS DS signs off on the cross-connection portion of the Applicant's U&O Permit. If the initial inspection **fails**, a re-inspection must be scheduled with MWS Development Services until it passes by emailing a <u>request</u> for a re-inspection back in to <u>DSInspections@Nashville.gov</u>

Associated Links & Forms

<u>Backflow Prevention Inspection Request</u> <u>Fee Schedule</u>



Step 24: MWS DS signs-off on water availability, sewer availability, and cross-connectivity elements of the Building Permit

Step Detail

After all meters and backflow prevention devices (if any) have passed and applicable permits are issued, MWS DS provides final sign off on the Building Permit. The Applicant receives email confirmation when the Building Permit is signed off. Information can be accessed in <u>ePermits</u>.

Associated Links & Forms

ePermits

(PEP) Step 25: Applicant submits As-Built construction plans for all water and/or sewer line extensions

Step Detail

Upon completion of construction of water and/or sewer, the Design Engineer shall provide MWS with a complete set of As-Built Plans in digital (DWG and PDF) format. All drawings must be completed and submitted prior to acceptance of the sewers or water mains into the public system and any connections being made.

Sewer plans shall be sealed by a licensed PE and/or a registered land surveyor and shall include actual field angles between lines, all actual service lines and tee locations, the distance of the end of the service line to property comers and lines and/or station and offset from sewer centerline to end of service line, the depth to the top of the end of the service line and shall reflect all alignment and grade changes.

Water line plans shall be sealed by a licensed PE and/or a registered land surveyor and shall include offset distance from the roadway centerline, or property line right of way, line depth, locations of hydrants, valves, reducers, tees, and pressure reducing devices where applicable.

As-Built Plans should be submitted via the process outlined in Step 7.